

Getting Started with PSK31 and JT65



Free PSK31 Software

Windows

DigiPan: www.digipan.net

Fldigi: www.w1hkj.com/download.html

Linux

Fldigi: www.w1hkj.com/download.html

OSX

Fldigi: www.w1hkj.com/download.html

Cocoamodem: www.w7ay.net/site/Applications/cocoaModem/

Free JT-65 Software

JT65-HF: www.arrl.org/hf-digital (under the "Resources" tab)

Interface Manufacturers

West Mountain Radio: www.westmountainradio.com

TigerTronics: www.tigertronics.com

Timewave: www.timewave.com

MFJ: www.mfjenterprises.com

Common PSK31 Frequencies (all frequencies USB)

3580 kHz

7040 kHz

14070 kHz

21070 kHz

28120 kHz

Common JT65 Frequencies

3576 kHz

7076 kHz

14076 kHz

21076 kHz

28076 kHz